

# ertic 2



150 Kg / 23.5 stones





**July 2020 edition:**

All rights reserved. Reproduction of these instructions in whole or in part in any form without express written permission from HMS-VILGO is strictly prohibited except for private use.

Information is regularly updated in the latest instructions versions. This can not engage the responsibility of HMS-VILGO in any way.

**Warning :**

The pics on this leaflet are not under contract.  
Therefore, HMS-VILGO has the right to change the products inside anytime.

**TABLE OF CONTENTS**

<b>1. PREAMBLE</b>	.....	page 3
<b>2. DESCRIPTION</b>	.....	page 3-6
2.1. Where to use <i>Vertic</i>		
2.2. General description		
2.3. Technical description		
2.4. Dimensional characteristics		
2.5. Labelling		
<b>3. VERTIC ASSEMBLING</b>	.....	page 8-13
3.1. Package contents		

*Removable central leaflet.*

<b>RECOMMENDED CHECKS</b>	.....	page 9
<b>EVALUATION OF THE NUMBER OF HOIST OPERATING CYCLES</b>	.....	page 10
<b>MAINTENANCE BOOK</b>	.....	page 11
<b>SPARE PARTS LIST</b>	.....	page 12

3.2. *Vertic* assembling (page 13)

<b>4. USE</b>	.....	page 14-17
4.1. First use		
4.2. <i>Vertic</i> use		
4.3. Safety		
4.4. Control box operating, battery charge		
4.5. Storage instructions		
<b>5. VERTIC MAINTENANCE</b>	.....	page 17-18
5.1. Weekly maintenance		
5.2. Annual maintenance		
5.3. Warranty		
5.4. Recycling		

## 1. PREAMBLE



***Before any use of the product :***

- 1- Read the leaflet : It will inform you how to use the product securely and must be at the disposal of the caring personnel.**
- 2- Product cleaning and disinfection : Please see chapter 5.**
- 3- Connection of the *Vertic* to the electrical network : Please see chapter 4.5**
- 4- Make sure of the good working of all functions.**

Only entitled staff who has read and understood these complete instructions can use *Vertic2*.

Always use *Vertic2* with a person who can belay the patient in case of blackout of the patient or failure of the hoist.

Use *Vertic2* following the maintenance instructions (see *Vertic2 maintenance* paragraph). If you have any doubt about *Vertic2* operating, please call HMS-VILGO After Sales Service for a diagnostic before using the hoist on a patient.

HMS-VILGO will not be responsible for damage if these warnings are not followed.

This manual contains all the technical information you need to make a good use of this product. This information has been carefully checked by HMS-VILGO. This is not an exhaustive list and HMS-VILGO is not responsible for any kind of mistakes or omissions.

## 2. DESCRIPTION

### 2.1. WHERE TO USE VERTIC2


---

The *Vertic2* is a lifting and transfer device. It is used to transfer disabled or elderly people:

- At home, to transfer the patient to an armchair, a toilet seat or a chair,
- In independent living structures,
- In a nursing or care home

Do not use *Vertic* outdoors or on a surface whose declivity could make the patient fell down (>5°).

2.2. DESCRIPTION GENERALE



2.3. TECHNICAL CHARACTERISTICS

Materials :	Steel
Finish :	Epoxy paint coating
Class:	I
Weight :	36 kg
Weight per item:	Chassis : 21 kg / 46 lb
	Mast + arms : 13 kg / 28.6 lb
	Leg rest : 2kg / 4.4 lb



Maximum patient weight to be transferred:	150 kg / 23.5 stones
---	----------------------

Electric protection classification :	<input type="checkbox"/> Class II
Applied parts :	 Type B

Electrical equipment conformed to NF EN 60 601-1 and to NF EN 60 601-2

Duty cycle :	2 min./18 min. (10%)
Input :	230V ~ 50 HZ
Actuator input :	24 V CC
Battery charge required time :	15 hrs
Battery autonomy :	40 cycles
Electrical equipment protection :	remote control : IP X6
	control box : IPX4
	actuator : IP X4

2.4. DIMENSIONAL CHARACTERISTICS



## 2.5. LABELLING

This label allows you:

To have all the necessary informations to make any intervention request for the after sales service thanks to the serial number and to the reference.

To ensure the follow up of the medical disposal.



It also gives to you the security loading charge for a good use.

There are 4 labels: One on the basis of the Vertic2, one on the electric actuator, one on the control box and one on the remote control.

Standards :



By this label, HMS-VILGO ensures that *Vertic2* hoist is conformed to European directive 89/336 referring to electromagnetic compatibility and to European directive 93/42 referring to medical devices.

## 3. VERTIC2 ASSEMBLING

### 3.1. PACKAGE CONTENTS

Les éléments suivants composent le carton :

1 Vertic 2 chassis:



Sling (x1)

1 box containing:



Control box (x1)



Main cable  
(x1)



Actuator cable  
(x1)



Remote control  
(x1)



Fixing screw  
CHC 6x80 (x2)



Anti-pulling up  
Cable kit (x1)




Spanner 6 section 5  
(x1)



## RECOMMENDED CHECKS

*Hoists are conformed to EN 10 535 standard which means that they can run 11 000 complete cycles under the conditions of uses they are designed for. Please, carefully consider how important it is to evenly check and maintain it in order to make sure that it is used under the standard specifications and under ours recommendations. We will not be responsible for any damage due to an abnormal use or to a too high number of cycles. You will find all the information you need for your checking and maintenance steps on pages 9, 10, 11 and 12.*



	Item to check	Check	replacement after 11 000 cycles
		Periodicity : at least once a year and before renting it	
1	pole / arms connection	- Check brass ring worn state - Check fixing screw worn state - Check stop-nut presence and assembling	✓
2	Control box	- Check emergency stop operating - Check battery charging	
3	Actuator	- Check charging operating	
4	Actuator / pole connection	- Check fixing screw worn state - Check stop-nut presence and assembling	✓
5	Electrical cables	- Check cables (pinching, plug state, cut ...)	
6	Pedals	- Check pedals operating - Check connecting rods worn state	
7	Back wheels	- Check braking system	
8	Side foot / pole support connection	- Check fixing worn state (screw nut + brass rings)	✓
9	Actuator / arms connection	- Check fixing screw worn state	✓
10	Arm hooks	- check the welding on all 3 hooks	
11	Emergency release	- Check electrical and manual release operating	
12	Sling	- Check seams	
13	Leg rest	- check the welding point of the leg rest - check the blocking device	
14	pole / pole support connection	- Check knobs presence and assembling - Check support pole welding	✓

\* Please refer to page 10 to obtain the list of the necessary parts

## EVALUATION OF THE NUMBER OF HOIST OPERATING CYCLES

This table below, indicates if the replacement of axis and spare parts is necessary, in function of the number of runs a day.

number of runs / a day	Oldness of the hoist (years)									
	1	2	3	4	5	6	7	8	9	10
1	365	730	1095	1460	1825	2190	2555	2920	3285	3650
2	730	1460	2190	2920	3650	4380	5110	5840	6570	<b>7300</b>
3	1095	2190	3285	4380	5475	6570	<b>7665</b>	<b>8760</b>	<b>9855</b>	<b>10950</b>
4	1460	2920	4380	5840	7300	<b>8760</b>	<b>10220</b>	<b>11680</b>	<b>13140</b>	<b>14600</b>
5	1825	3650	5475	7300	<b>9125</b>	<b>10950</b>	<b>12775</b>	<b>14600</b>	<b>16425</b>	<b>18250</b>
6	2190	4380	6570	<b>8760</b>	<b>10950</b>	<b>13140</b>	<b>15330</b>	<b>17520</b>	<b>19710</b>	<b>21900</b>
7	2555	5110	<b>7665</b>	<b>10220</b>	<b>12775</b>	<b>15330</b>	<b>17885</b>	<b>20440</b>	<b>22995</b>	<b>25550</b>
8	2920	5840	<b>8760</b>	<b>11680</b>	<b>14600</b>	<b>17520</b>	<b>20440</b>	<b>23360</b>	<b>26280</b>	<b>29200</b>
9	3285	6570	<b>9855</b>	<b>13140</b>	<b>16425</b>	<b>19710</b>	<b>22995</b>	<b>26280</b>	<b>29565</b>	<b>32850</b>
10	3650	<b>7300</b>	<b>10950</b>	<b>14600</b>	<b>18250</b>	<b>21900</b>	<b>25550</b>	<b>29200</b>	<b>32850</b>	<b>36500</b>
11	4015	<b>8030</b>	<b>12045</b>	<b>16060</b>	<b>20075</b>	<b>24090</b>	<b>28105</b>	<b>32120</b>	<b>36135</b>	<b>40150</b>
12	4380	<b>8760</b>	<b>13140</b>	<b>17520</b>	<b>21900</b>	<b>26280</b>	<b>30660</b>	<b>35040</b>	<b>39420</b>	<b>43800</b>
13	4745	<b>9490</b>	<b>14235</b>	<b>18980</b>	<b>23725</b>	<b>28470</b>	<b>33215</b>	<b>37960</b>	<b>42705</b>	<b>47450</b>
14	<b>5110</b>	<b>10220</b>	<b>15330</b>	<b>20440</b>	<b>25550</b>	<b>30660</b>	<b>35770</b>	<b>40880</b>	<b>45990</b>	<b>51100</b>
15	<b>5475</b>	<b>10950</b>	<b>16425</b>	<b>21900</b>	<b>27375</b>	<b>32850</b>	<b>38325</b>	<b>43800</b>	<b>49275</b>	<b>54750</b>
16	<b>5840</b>	<b>11680</b>	<b>17520</b>	<b>23360</b>	<b>29200</b>	<b>35040</b>	<b>40880</b>	<b>46720</b>	<b>52560</b>	<b>58400</b>
17	<b>6205</b>	<b>12410</b>	<b>18615</b>	<b>24820</b>	<b>31025</b>	<b>37230</b>	<b>43435</b>	<b>49640</b>	<b>55845</b>	<b>62050</b>
18	<b>6570</b>	<b>13140</b>	<b>19710</b>	<b>26280</b>	<b>32850</b>	<b>39420</b>	<b>45990</b>	<b>52560</b>	<b>59130</b>	<b>65700</b>
19	<b>6935</b>	<b>13870</b>	<b>20805</b>	<b>27740</b>	<b>34675</b>	<b>41610</b>	<b>48545</b>	<b>55480</b>	<b>62415</b>	<b>69350</b>
20	<b>7300</b>	<b>14600</b>	<b>21900</b>	<b>29200</b>	<b>36500</b>	<b>43800</b>	<b>51100</b>	<b>58400</b>	<b>65700</b>	<b>73000</b>
21	<b>7665</b>	<b>15330</b>	<b>22995</b>	<b>30660</b>	<b>38325</b>	<b>45990</b>	<b>53655</b>	<b>61320</b>	<b>68985</b>	<b>76650</b>
22	<b>8030</b>	<b>16060</b>	<b>24090</b>	<b>32120</b>	<b>40150</b>	<b>48180</b>	<b>56210</b>	<b>64240</b>	<b>72270</b>	<b>80300</b>
23	<b>8395</b>	<b>16790</b>	<b>25185</b>	<b>33580</b>	<b>41975</b>	<b>50370</b>	<b>58765</b>	<b>67160</b>	<b>75555</b>	<b>83950</b>
24	<b>8760</b>	<b>17520</b>	<b>26280</b>	<b>35040</b>	<b>43800</b>	<b>52560</b>	<b>61320</b>	<b>70080</b>	<b>78840</b>	<b>87600</b>
25	<b>9125</b>	<b>18250</b>	<b>27375</b>	<b>36500</b>	<b>45625</b>	<b>54750</b>	<b>63875</b>	<b>73000</b>	<b>82125</b>	<b>91250</b>
26	<b>9490</b>	<b>18980</b>	<b>28470</b>	<b>37960</b>	<b>47450</b>	<b>56940</b>	<b>66430</b>	<b>75920</b>	<b>85410</b>	<b>94900</b>
27	<b>9855</b>	<b>19710</b>	<b>29565</b>	<b>39420</b>	<b>49275</b>	<b>59130</b>	<b>68985</b>	<b>78840</b>	<b>88695</b>	<b>98550</b>
28	<b>10220</b>	<b>20440</b>	<b>30660</b>	<b>40880</b>	<b>51100</b>	<b>61320</b>	<b>71540</b>	<b>81760</b>	<b>91980</b>	<b>102200</b>
29	<b>10585</b>	<b>21170</b>	<b>31755</b>	<b>42340</b>	<b>52925</b>	<b>63510</b>	<b>74095</b>	<b>84680</b>	<b>95265</b>	<b>105850</b>
30	<b>10950</b>	<b>21900</b>	<b>32850</b>	<b>43800</b>	<b>54750</b>	<b>65700</b>	<b>76650</b>	<b>87600</b>	<b>98550</b>	<b>109500</b>

Keep using the hoist.

**Foresee axles and spare parts replacement.**

**\* Replace axles and spare parts.**










\* See spare parts list page 10

MAINTENANCE BOOK

HOIST REFERENCE:		
Serial number :		Date of 1st use :


DATE / Number of cycles evaluated	MAINTENANCE AND QUALITY CHECKING	NAME & APPROVALS

## SPARE PARTS LIST


Part	Description	Item code	Qty	Location	Replacement after 11 000 cycles
	LA31 6000N actuator	A501228	1	/	
	CBJH1 control box	A501662	1	/	
	HB31 remote control	A501217	1	/	
	M10x18 knob	A300023	2	pole / cross piece connection	
	TH10x55 screw	A001128	1	actuator / arms connection	✓
	Ø 8 stop nut	A001072	1		
	Ø 10/20 washer	A001061	2		
	Ø 10 Lg 64+20 articulation pole/cross piece axle	A001128	1	actuator / pole connection	✓
	Ø 8 stop-nut	A001072	2		
	Ø 8 washer	A001061	2		
	pole / actuator Lifty 4 fixing plate	A501244	2		
	Ø 12 stop nut	A001080	2		
	HH 12x80 screw	A501251	2		
	Bague laiton Ø 22/10	A002016	2	Pole / arms connection	✓
	Ø 10 Lg 56+20 articulation pole/arms	A501067	1		
	Ø 8 stop nut	A001004	2		
	Ø 8 washer	A001062	2		
	Ø 40/3.4 brass ring or Ø 40/3 brass ring	A001066 A001089	4	Side foot / cross piece connection	✓
	pedals bushing	A000840	4	pedals	✓

## 3.2. PLUGGING


### 1 *Plugging / Anti-Pulling up cable*



1/ Plug the remote control and the actuator cables and plug the shutter.



2/ Put the anti-pulling up hood in placing the cables through the opening.




3/ Screw the hood to the control box with a crossed screw-driver.

### 2 Fix the control box to the pole in screwing the 2 cross screws.




### 3 Plug the actuator cable to the control box and to the actuator: You can lock this connection with the supplied locking clip.



### 4

Your *Vertic2* is now ready to run.



## 4. USE



### 4.1. FIRST USE

The battery delivered with the *Vertic2* is fully charged so that you can start using the hoist immediately. However check the hoist has been assembled properly as explained in paragraph 3, and try it without a patient to get familiar with its use and functions.

### 4.2. VERTIC 2 USE

#### 4.2.1 Sling installation and operating :

Reminder : Sling is adjustable. User is responsible for adjusting it in order to not hurt the patient. *Vertic2* is delivered with its sling. See the user instruction below.



**1/ Undo the abdominal belt.**

**2/ Put the sling behind the patient's back and slide the A and B parts to be hooked, under his/her arms.**

**3/ fasten the belt around the patient's belly.**

**4/ Attach snap hook A to one of the C rings**

**5/ Attach snap hook B to one of the D rings**

#### 4.2.2 Transferring the patient:

While the patient is seated on a chair, armchair or on the edge of electrical bed :

**1/ Bring the *Vertic* closer and place the patient's feet on the foot rest.**

(depending on the situation and layout of the space available, narrow or widen the side feet to get close to the patient)

**2/ Adjust the leg-rest up or down to block the patient's shins against it** (pull the locking screws on each side of the pole)


**3/ Lock brakes**

**4/ Set up the sling**

**5/ Press the up button on the handset (↑) to lift up the main pole** (make sure the sling is not stuck and does not injure the patient while doing this).

**6/ Unlock brakes to transfer the patient.**

**7/ Press the down button (↓) to bring the patient down.**



### 4.3. SAFETY

**crushing safety:** *Vertic 2* runs with a single-acting actuator. Any obstacle on its way will automatically stop its going-down.

**Emergency stop :** the *Vertic 2* emergency stop button is located on the control box. Push it to stop the lifting or going-down. Push it again to unlock it.



**Electric safety :** lifting and going-down are locked when *Vertic2* is connected to charge battery.

**Emergency going-down** (only use when patient is stuck above and that it is impossible to go down using the remote control) : There are two actuator release systems:

#### 1/ Electrical release :

To go down, push the blue switch located under the emergency stop.



#### 2/ Manual release :

Push down (1) and turn to the right (2) the red ring of the actuator.  
This function can be used if the electrical system is not efficient.



**A third person must assist the patient during the entire emergency going-down process.**

### 4.4. CONTROL BOX OPERATING, BATTERY CHARGE :

If the charging level is too weak, an alarm sounds (in a constant way) when the control box is activated. The charging of the battery is then necessary.

The control box has its own integrated charger. To charge batteries, connect the control box to the 220 VAC main power line, until the green led turn on indicating batteries are charged (approximately 12 hours).




**The *Vertic 2* must be connected to a network which is in accordance with the NFC 15-100 and NFC 15-211 ( 230 V Electric plug + ground connection) for France and CEI 364 for other destinations.**

**Make sure that the power supply of the control box (you can find it on the label), is in accordance with the establishment power supply.**

**It is advisable to connect the device on a power fitting protected by a differential circuit breaker of 30 mA Maximum, in accordance with the CEI 364-5-53 publication.**

Warning, the loading of the batteries works only if the emergency button is out of power (put it on the position 'on' to load the batteries).



To make batteries last longer, they must be recharged every night.

## 4.5. STORAGE INSTRUCTIONS:

Do not expose to moisture.

Store in a temperate dry place (5°C to 40°C).

Charge battery before using it after a long time off.

Handling and stocking of the lift has to be done in order to avoid any impact, falling or damage of the material.

## 5. VERTIC2 MAINTENANCE

### 5.1 WEEKLY MAINTENANCE

#### Sling :

Check the sling by looking at its seams condition: immediately replace a sling that starts to show any tear.

#### Electrical parts:

Test the emergency stop switch while lifting and lowering the support beam.

Look at the electrical cables cover.

Test crushing safety system by placing an item on the support beam going-down way.

#### Chassis :

Check the brake of the back wheels.

Look at the global geometry on the *Vertic2* (no bent item).

Make sure that the 4 wheels are well positioned on the ground.

Make sure that there is no play between the support beam and the pole.

#### Sling cleaning instructions:

 86°F (or 30°C) machine wash

-



Do not dry clean

-



Do not iron



### Cleaning of the Vertic 2:

Before any intervention on the *Vertic2*, disconnect it from the power and take out the control box. Follow this cleaning protocol.

**1-Use a non-woven fabric and a relevant cleaning solution (ANIOS DETERGENT DESINFECTANT SURFACES HAUTES Or any similar product).**

**Apply the indicated dosage.**

**2-Clean all surfaces.**

**3-Let dry.**

#### **WARNING:**

- Do not splash water onto the device
- Do not use high-pressure cleaning

#### **STRICTLY FORBIDDEN:**

- pure alcohol (PA)
- Acetone
- tetrachloroethylene and trichlorethylene
- any type of solvents
- abrasive cleaning products
- any type of wax

## **5.2 ANNUAL MAINTENANCE**

We recommend a complete annual check up on this type of device. Please find on page 9-12 the summary of the necessary controls and checkups you need to perform on the hoist; as well as the maintenance sheet to log in all interventions.

## **5.3 WARRANTY**

Your *Vertic2* hoist has its own serial number. This number is on a label on the chassis and is repeated on every electrical part. To make a claim using the warranty, you need to return the faulty part, with its serial number label to your retailer who will contact us.

The warranty of this product is valid for 5 years (except battery: 1 year).

**ANY RETURN WITHOUT SERIAL NUMBER LABEL WILL NOT BE COVERED BY THE WARRANTY.**

The warranty does not cover any breakdown due to inappropriate or wrong use or maintenance, in spite of the specifications and use instructions stated in this manual. (electrical shock, torn cables etc.)

Warranty does not cover any breakdown or malfunction due to parts being swapped over or replaced with used or unapproved parts.

## **5.4 RECYCLING**

Recycling must be done according to the type of materials and components and in compliance with the current recycling regulations. Disposal and destruction of the faulty parts must be handled by an agreed recycling company.







*Cachet distributeur*



**Site de Lille** : Parc Eurasanté – 243 Rue Allendé  
**59120 LOOS LEZ LILLE**  
Tél : +33 (0)3 20 84 81 50 – Fax : + 33 (0)3 20 59 58 08

**Site de Bergerac** : Rte de Sainte Alvère - Creysse BP 212  
**24102 BERGERAC Cedex**  
Tel. : +33 (0)5 53 74 45 50 – Fax : +33 (0)5 53 63 06 07

[www.hms-vilgo.com](http://www.hms-vilgo.com)